

ВРУ-21Л-400-300К

"Рабочий
ввод"

"Резервный
ввод"

PEN1
1QF
400A
(ABC)1

PEN2
2QF
400A
(ABC)2

ABP

KM1

KM2

WH

ТШП
400/5A

(ABC)3

(ABC)4
N
PE

320A

16A

16A

16A

16A

16A

